

Montageanleitung

Mounting instructions



Lenkererhöhungen
Risers

V3021 & VF3021

Passend für <i>fitting for:</i>	Lenker <i>handlebar:</i>	Bohrungsabstand <i>hole distance:</i>
V3021	22mm (22,2)	32-40mm
VF3021	28mm (28,6)	37,5-45,5mm





VOIGT MOTO TECHNIK



Lieferumfang:

- 2x Lenkererhöhung mit Versatz (1)
- 2x Obere Klemmung (2)
- 8x Innensechskantschraube M8x25 (3)
- 6x Schraubenkappen
- 1x Allgemeine Betriebserlaubnis
- 1x Montageanleitung & Montagehinweise

Hinweis: Es handelt sich hierbei um universelle Bauteile. Für manche Fahrzeuge liegt zusätzliches Montagematerial bei. Bitte achten Sie nach erfolgter Montage darauf, dass auch bei voll eingeschlagenem Lenker der Brems- und Kupplungsschlauch, Züge und Kabel weder spannen noch scheuern.



Content of delivery:

- 2x handlebar risers with offset (1)
- 2x top clamps (2)
- 8x allen bolts M8x25 (3)
- 6x screw hats
- 1x product certificate
- 1x mounting instructions

Advice: These are universal risers. Additional assembly material is included for some vehicles. Once the risers are installed, make sure to check when the handlebars are at full steering angle, that there is no tension on the throttle cable, clutch and brake lines/hoses and that none of these rub on other components.

Montageanleitung

Mounting instructions



