

Montageanleitung

Mounting instructions



Lenkererhöhungen
Risers

ZV3021

Passend für / fits for:
Fahrzeuge mit 25,4mm (1 Zoll) Lenker und
einem Bohrungsabstand von 36 - 42mm.

Vehicles with 25,4mm (1 inch) handlebars and
a hole spacing of 36 - 42mm.





VOIGT MOTO TECHNIK



Lieferumfang:

- 2x Lenkererhöhungen (1)
- 8x Innensechskantschrauben M8x25 (2)
- 6x Schraubenkappen
- 1x Allgemeine Betriebserlaubnis
- 1x Montageanleitung & Montagehinweise

Hinweis: Es handelt sich hierbei um universelle Bauteile. Bitte achten Sie nach erfolgter Montage darauf, dass auch bei voll eingeschlagenem Lenker der Brems- und Kupplungsschlauch, Züge und Kabel weder spannen noch scheuern.



Content of delivery:

- 2x handlebar risers (1)
- 8x allen bolts M8x25 (2)
- 6x screw covers
- 1x product certificate
- 1x mounting instructions

Advice: These are universal risers. Once the risers are installed, make sure to check when the handlebars are at full steering angle, that there is no tension on the throttle cable, clutch and brake lines/hoses and that none of these rub on other components.

Montageanleitung

Mounting instructions



